

Model No.FN001G Cordless Brad Nailer



Model No.FN001G Cordless Brad Nailer



Model No.FN001G Cordless Brad Nailer

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/ Old	Note1	Note2
001	183S31-9	Housing set		1	*		
C10	263005-3	Rubber pin 6		2	*		
C20	252126-6	Hex. lock nut M4-7		2	*		
001		INC. 18			*		
001-1	183V36-7	HOUSING SET	S	1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	8007R2-2	XGT logo label		1			
001-1		INC. 18					
002	811922-7	Name plate FN001G		1			
003	266199-3	Hex. socket head bolt M4X6		2			
004	266130-9	Binding head tapping screw 3X16		1			
005	413327-3	Housing R cover		1			
006	266130-9	Binding head tapping screw 3X16		9			
007	911108-4	Pan head screw M4X8 WR		2			
008	620507-6	LED circuit		1			
009	620F54-3	Controller		1			
010	632P49-4	Terminal unit		1	*		
010-1	632W77-1	Terminal unit	<	1			
011	811926-9	Serial No. label FN001G		1			
012	140W22-7	Switch complete		1			
013	456799-9	Trigger lock		1			
014	632S31-1	Switch unit		1			
015	232370-1	Compression spring 5		1			
016	413328-1	Trigger		1			
017	140W22-7	Switch complete		1			
018	183S31-9	Housing set		1	*		
C10	263005-3	Rubber pin 6		2	*		
C20	252126-6	Hex. lock nut M4-7		2	*		
018		INC. 1			*		
018-1	183V36-7	HOUSING SET	S	1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	8007R2-2	XGT logo label		1			
018-1		INC. 1					
019	915101-0	Binding head screw M4X6		4			
020	413326-5	Front cover		1			
021	347528-0	Upper plate		1			
022	256882-0	Flat fillister head pin 4		1			
023	347791-5	Driver		1			
024	347793-1	Rail		1			
025	313352-3	Counter weight A		2			
026	310925-3	Counter weight B		2			
027	251566-5	Hex. socket head bolt M4X6 W		2			
028	347146-4	Pinion guide		2			
029	413330-4	Counter weight holder		4			

030	136104-3	Spur gear assembly		2			
032	326902-5	Pinion shaft		2			
033	251566-5	Hex. socket head bolt M4X6 W		4	*		
033-1	266199-3	Hex. socket head bolt M4X6	<	4			
034	347801-8	Guide rail L		1			
035	347802-6	Guide rail R		1			
036	327756-3	Guide bolt		1			
037	347796-5	Bottom plate		1			
038	313353-1	Bottom holder		1			
040	232670-9	Compression spring 16		1			
041	347794-9	Hammer		1			
042	422664-4	Cushion		1			
043	253804-1	Flat washer 6		1			
044	922107-1	Hex. socket head bolt M4X8		1			
045	312A82-9	Holder		1			
046	252273-3	Hex. nut M6		1			
047	347797-3	Counter stopper		1			
048	422663-6	Counter cushion		2			
049	327757-1	Weight		2			
050	232671-7	Compression spring 9		2			
051	327754-7	Guide pipe		2			
052	347795-7	Gear plate		1			
053	266901-4	Binding head tapping screw 4X14		1			
054	140Y40-7	Spur gear 64 complete		1			
055	347800-0	Lock arm		1			
056	327753-9	Lock pin		1			
057	140Y39-2	Base plate complete		1			
058	227860-7	Spur gear 29		1			
059	962067-5	Retaining ring R-17		1			
060	211099-2	Ball bearing 689ZZ		1			
061	227859-2	Spur gear 9		1			
062	211343-7	Ball bearing 688ZZ		1			
063	312A84-5	Bearing case		1			
064	265911-8	Hex. socket head bolt M4X8		2			
065	922117-8	Hex. socket head bolt M4X12		4			
066	347523-0	Plate		1			
067	127761-8	Driver guide assembly		1			
067		INC. 68-73					
068	347523-0	Plate		1			
069	922102-1	Hex. socket head bolt M4X6		3			
070	313350-7	Driver guide		1			
071	232512-7	Compression spring 3		1			
072	313351-5	Center plate		1			
073	313349-2	Set plate		1			
074	961017-7	Stop ring (EXT) E-3		1			
076	413321-5	Contact arm		1			
077	327755-5	Adjuster shaft		1			
078	347799-9	Arm		1			
079	127763-4	Adjuster assembly		1			
079		INC. 98-101					
080	232514-3	Torsion spring 7		1			

081	413325-7	Adjuster cover		1			
082	266007-8	Binding head tapping screw 3X10		1			
083	310176-8	Stopper		1			
084	233018-8	Compression spring 3		1			
085	347792-3	Pusher		1			
086	413324-9	Magazine		1			
087	459313-0	Sleeve		2			
088	265A52-6	Hex. socket head bolt M4X14		1			
089	234325-2	Compression spring 6		2			
090	346774-2	Nail plate		1			
091	140Y45-7	Slide door complete		1			
092	413329-9	Lever		1			
093	262054-7	Urethane ring 3		1			
094	233117-6	Compression spring 6		1			
095	256877-3	Pin 3		1			
097	136392-2	Magazine assembly		1			
097		INC. 74,76-95					
098	413323-1	Adjuster guide		1			
099	216031-1	Steel ball 2.3		1			
100	234254-9	Compression spring 2		1			
101	413322-3	Adjuster		1			
102	127760-0	Gear assembly		1			
103	266490-9	Pan head tapping screw 2X6		3			
104	652069-6	Flat head screw M3X6		3			
105	629464-5	Stator		1			
106	619676-8	Rotor		1			
107	265B75-0	Hex. socket head bolt M4X8 WG		2			
108	232672-5	Leaf spring		1			
109	232673-3	Leaf spring		1			
110	8007R2-2	XGT logo label		1	*		
111	347798-1	Holder plate		1			
112	136444-9	Spur gear 9 assembly		1			
112		INC. 59-63					
A02	251314-2	Truss head screw M4X12		1			
A03	346317-0	Hook		1			
A04	422665-2	Nose adapter S		1			
A05	783201-2	Hex. wrench 3		1			