


ROUNDLINE

Dimensioneringsguide

Så här väljer du radiatorer i förhållande till utetemperatur och rumsstorlek.

Lägsta utetemperatur	300 W	600 W	800 W	1000 W	1200 W	1500 W
-40°C	1-3 m ²	3-6 m ²	6-8 m ²	8-10 m ²	10-12 m ²	12-15 m ²
-30°C	1-4 m ²	4-7 m ²	7-10 m ²	10-12 m ²	12-15 m ²	15-19 m ²
-20°C	1-5 m ²	5-9 m ²	9-13 m ²	13-15 m ²	15-19 m ²	19-24 m ²

Sortimentsöversikt



Tego Kundtjänst 0418-45 58 20



TEGO SYSTEM AB, Box 43, SE-261 22 Landskrona, Tel +46 (0)418-45 58 00, Fax +46 (0)418-45 58 01
Bg 5625-3735, Pg 3 58 97-8, Nordea SWIFT NDEASESS IBAN SE47 3000 0000 0307 6181 0730
Vat no SE556124910201, Styrelsens säte: Landskrona, Innehar F-skattsedel, www.tego.se, info@tego.se