

TELLDUS 

QUICK GUIDE

Easy installation of your
Telldus Z-Wave Mini Plugin Switch





CONNECTING YOU AND YOUR HOME

1. INCLUDE THE DEVICE IN TELLDUS LIVE

Lägga till enheten i Telldus Live • Inkludere enheten i Telldus Live

• Das Gerät in Telldus Live einschließen • Laitteen liittäminen Telldus Live • Inkludere enheden i Telldus Live



1.3

live.telldus.com

Add a new device



1.4

live.telldus.com



433,92 MHz

Add new device wizard ✕


Include Z-Wave device:

- 1 Include device by enabling inclusion mode on the device within 60 seconds.
- 2 This is usually done by clicking three times on the button on the device. Refer to the manual of your device on how to enter inclusion mode.
- 3 When in inclusion mode the device will automatically be included.


14 sec

Interview command class 2 of 12... (23% done)

Cancel



Follow the built-in wizard • Följ den inbyggda guiden • Følg den innebygde veiviseren • Folgen Sie den Anweisungen des integrierten Assistenten • Seuraa sisäänrakennettua ohjattua asennusta • Følg den indbyggede vejledning



2. CONTROL THE DEVICE IN TELLDUS LIVE

Styra enheten i Telldus Live • Styre enheten i Telldus Live • Das Gerät in Telldus Live steuern • Laitteen ohjaaminen Telldus Live • Styring af enheden i Telldus Live

2.1

live.telldus.com

live.telldus.com

My Devices



2.2

live.telldus.com



My lamp


OFF ON



3. CONTROL THE DEVICE MANUALLY

Styra enheten manuellt • Styre enheten manuellt • Das Gerät manuell steuern • Laitteen ohjaaminen manuaalisesti • Manuel styring af enheden


3.1







4. EDIT THE DEVICE

Redigera enheten • Redigere enheten • Das Gerät bearbeiten •
Muokkaa laitetta • Redigér enheden

4.1 live.telldus.com

a. > live.telldus.com > My Devices 

b.  My lamp   


4.2 live.telldus.com





Edit device 

5. EXCLUDE THE DEVICE

- Exkludera enheten • Ekskluder enheten • Das Gerät ausschließen
- Poista laite • Ekskludér enheden

5.1 live.telldus.com

a. > live.telldus.com > My Devices 

b.  My lamp   

5.2 live.telldus.com

Edit device 


5.1

live.tellus.com

Exclude device



5.1



TECHNICAL SPECIFICATIONS

Tekniska Specifikationer • Tekniske Spesifikasjoner • Technische Spezifikationen • Tekniset Tiedot • Tekniske Specifikationer

Product Name	Telldus Z-Wave Mini Plugin Switch
Type Number	TZWP-102
Function	On/Off, Energy Meter, Surge Protection
Voltage	230V~ 50Hz
Input Current	Max 8A
Max Load	1800W Resistive
Surge Protection	>1500V
Energy Metering Accuracy <100W	<±2W
Energy Metering Accuracy >100W	<±2%
Operating Ambience	0°C–25°C; 5%–75% RH
Button Function	Include/Exclude/Power/Reset
IP Class	IP20
Protocol	Z-Wave
Chip Version	500 Plus Series
Frequency	868.42MHz (EU)

Frequency range	868.0-868.6MHz & 869.7-870.0MHz
Transmitting Range	up to 30m (open air)
Pollution Degree	2
Maximum RF Output Power	1dBm
Rated Impulse Withstand Voltage	2.5KV
Duty-type	S1, Continuous duty
Number of Operating Cycles	10000
Circuit Disconnection	Micro-disconnection
Glow-wire Temperature	650°C
Non-replaceable Built-in Protection	Thermal Fuse 10A 84°C
PTI	175
Cooling Condition	Not required forced cooling
Type of Connection and Load	Single Pole Single Load (single pole disconnection)
Test Condition	Maximum rated resistive current

Do not connect after each other.
 Not to be used in direct sunlight.



Download complete technical manual and find more useful information at telldus.com

Ladda ner fullständig teknisk manual och hitta mer nyttig information på telldus.com

Last ned den komplette tekniske håndboken og finn mer nyttig informasjon på telldus.com

Laden Sie das vollständige technische Handbuch herunter und finden Sie weitere nützliche Informationen unter telldus.com

Lataa kattava tekninen opas ja katso lisätietoja seuraavasta osoitteesta telldus.com

Download den fulde tekniske vejledning, og find mere nyttig information på telldus.com



facebook.com/telldus



[@telldus](https://instagram.com/telldus)

Telldus Technologies AB
Kabelvägen 7, 311 50 Falkenberg, Sweden
www.telldus.com • support.telldus.com