



RETIRER ET INSTALLER LE TIRROIR
REMOVE AND INSTALL THE DRAWER




RETIRER
REMOVE


1



2




3




INSTALLER
INSTALL

1



2



3

