

Clou ATV 2500 tukkikärry



WARNING Read and Understand this instruction sheet completely before using the Trailer.

1. Do not overload.
2. Wheel working pressure is 1.6-1.8BAR. Wheel need feed and check air again if Trailer not using for 1 month.
3. Not for highway use. Trailer speed is lower than 30KM/h for off road.
4. Always keep arms, feet and legs, etc. out from under the trailer tongue while hitching, unhitching or moving the trailer.
5. Children should always be kept at a safe distance from Trailer operation.
6. Block tires during storage and prior to Trailer operation.
7. Make sure the trailer coupling is securely connected to the Trailer coupler ball before attempting to unblock and move the trailer.

