

bathlife

Thermostatic shower /bath mixer





Installation Instruction

- Supply lines should be purged to clean impurities before connecting the unit (hot water on left, cold water on right).
- 2. Screw the S-Connectors into supply lines. The S-Connectors can be adjusted in 150"20mm, from hot water supply to cold water supply so that the mixer can be adjusted during installation.
- 3. Put decorative covers on the S-Connectors closely to the wall.
- 4. Put the washers into the nuts of the mixer, and then screw the nuts to tighten the mixer onto the S-Connectors. The mixer should be aligned with the wall and floor horizontally. The hot water supply should be connected to the left and the cold water supply to the right.
- 5. Leakage test: turn on/off the temperature control handle and multifunctional handle. If no leakage is found, the installation is done.

Application


 The security stop is 38°C. Press the security stop and turn the handle fore and back, water temperature will become hotter or colder.

Cleaning and maintenance

- Use soap and water to remove lime stains from chrome surface. Don't use acidic detergents, scouring pads or steel wool; otherwise the chrome parts will be damaged
- Use soap and water to clean installation accessories, such as plastic or rubber components. Don't use acidic detergents, scouring pads, alcohol cleaners or steel wool.



| Nominal Diameter | M26x1.5 |
|----------------------|----------------|
| General Medium | Water |
| Water Pressure | 0.05Mpa-1.0Mpa |
| Recommended Pressure | 0.1Mpa-0.6Mpa |
| Temperature Range | 4!C - 90!C |



Product accessories