

# Broil King®

---

---



## Broil King













BARON S 440 PRO IR  
8759-62  
8759-63




## Broil King

BARON S 490 PRO IR  
8759-82  
8759-83  
8759-86


## HARDWARE INCLUDED

S21124		(8)	Y-29304		(2)
Y-12865		(26)	Y-11793		(6)
Y-11551		(2)	Y-12124		(2)
56039-211A		(1)	Y-32001-151		(4)
Y-12229		(1)	S21235		(2)
 <p style="text-align: center;">#3 ROBERTSON</p> <p style="text-align: center;">#2 ROBERTSON</p>			S21233		(2)
20005-000					(1)





## TOOLS REQUIRED




1




2





3

(2) 




4


(8) 




5



(4)





(4)




6

(2)




# 7

(2)




(1)





8


(2) 




9

(2) 








# 11

(4) 

(1)




(1)




# 12



(4)





(2)




# 13





# 14







# 16





(4)




# 17

(6)







# 19







# 20








# 22


- (2) 
- (2) 







# 24


- (2) 
- (2) 



25



26



**PARTS LIST / LISTE DES PIÈCES**

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8759-62</u>	<u>8759-63</u>	<u>8759-82</u>	<u>8759-83</u>	<u>8759-86</u>
1	50909-E441	CASTING BOTTOM	1	1	1	1	1
2	66005-304	LID ASSEMBLY	1	1	1	1	1
3	52019-911	FIRE BOX END CAP - LH	1	1	1	1	1
4	52019-931	FIRE BOX END CAP - RH	1	1	1	1	1
5	52049-042	HEAT SHIELD	3	3	3	3	3
7	Y-11544S	SCREW - BURNER	4	4	4	4	4
8	S21242	BURNER CLIP	4	4	4	4	4
12	52315-151	HOOD PANEL	1	1	1	1	1
13	52035-914	FIRE BOX FRONT TRIM	1	1	1	1	1
18	52005-281	GRID - SINGLE CI	4	4	4	4	4
20	52005-991	GRID - WARMING RACK	1	1	1	1	1
21	59805-032IR	CONTROL ASSEMBLY	1	1	1	1	1
	59805-033IR	CONTROL ASSEMBLY	1	1	1	1	1
	59805-072IR	CONTROL ASSEMBLY	1	1	1	1	1
	59805-073IR	CONTROL ASSEMBLY	1	1	1	1	1
	59805-076IR	CONTROL ASSEMBLY	1	1	1	1	1
22	22025-904	COLLECTOR BOX	1	1	1	1	1
24	10111-16A	CONNECTOR HOSE	1	1	1	1	1
25	52929-104D	BURNER	4	4	4	4	4
	52929-104E	BURNER	4	4	4	4	4
26	22001-769	CONTROL KNOB	4	4	4	4	4
26A	22001-669	CONTROL KNOB	1	1	2	2	2
27	22002-264	CONTROL BEZEL	4	4	4	4	4
27A	22001-164	CONTROL BEZEL	1	1	2	2	2
28	52005-854	CONTROL COVER	1	1	1	1	1
	52005-894	CONTROL COVER	1	1	1	1	1
29	Y-12678	BEZEL STOP	1	1	1	1	1
30	Y-12674	KNOB ADAPTER	1	1	1	1	1
31	52009-918	EDGE CAP - LH	1	1	1	1	1
32	52009-938	EDGE CAP - RH	1	1	1	1	1
33	10153-93	QUICK DISCONNECT FITTING	1	1	1	1	1
34	S13473-IR	HOSE-SIDE BURNER	1	1	1	1	1
34A	Y-11230	COTTER PIN	1	1	1	1	1
35	52039-101	SIDE BRACE	2	2	2	2	2
36	52809-957	TUBE-REAR BURNER	1	1	1	1	1
37	53139-908	SHELF BRACKET	4	4	4	4	4
38	Y-12620	SHELF LOCK CLIP	4	4	4	4	4
39	52045-111	BRACE - FRONT / REAR	2	2	2	2	2
41	10342-E13	ELECTRODE	1	1	1	1	1
42	10342-E22	ELECTRODE	1	1	1	1	1
43	10153-79	FITTING	1	1	1	1	1
44	10342-43	ELECTRONIC IGNITOR	1	1	1	1	1
44A	10342-44	ELECTRONIC IGNITOR	1	1	1	1	1
44B	25070-925	WIRE - IGNITOR	1	1	1	1	1
	25070-93	BUTTON - IGNITOR	1	1	1	1	1

**PARTS LIST / LISTE DES PIÈCES**

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8759-62</u>	<u>8759-63</u>	<u>8759-82</u>	<u>8759-83</u>	<u>8759-86</u>
45	10693-074	ORIFICE	1	.	1	.	.
	10693-081	ORIFICE	.	1	.	1	.
	10693-121	ORIFICE	.	.	.	.	1
46	23039-274	GREASE PAN SUPPORT	2	2	2	2	2
47	20153-64	ORIFICE ADAPTER	1	1	1	1	1
48	52004-007	GREASE PAN	1	1	1	1	1
49	51009-007	GREASE TRAY	1	1	1	1	1
50	52059-101	GREASE TRAY SUPPORT	1	1	1	1	1
51	52009-104	FLAV-R-WAVE®	4	4	4	4	4
52	10110-74	TUBE - COMPRESSION FITTING	1	1	1	1	1
54	22009-901	GREASE PAN	1	1	1	1	1
56	24005-12A	HANDLE	1	1	1	1	1
58	54009-936	BEZEL	2	2	2	2	2
59	10081-BK630	NAMEPLATE	1	1	1	1	1
60	10571-6	HEAT INDICATOR	1	1	1	1	1
65	20005-000	MATCH LIGHT - STICK	1	1	1	1	1
68	51275-114A	DOOR	1	1	1	1	1
69	51275-134A	DOOR	1	1	1	1	1
70	21071-13	HANDLE	2	2	2	2	2
71	21070-13	BEZEL	4	4	4	4	4
78	56039-211A	MAGNET BRACKET	1	1	1	1	1
80	51189-101	SIDE PANEL	2	2	2	2	2
81	Y-11992	SCREW 1/4-20 x 2 1/4	4	4	4	4	4
82	51605-104	BASE TRIM	1	1	1	1	1
83	51239-901	CABINET BRACKET	1	1	1	1	1
87	Y-11793	NUT 1/4-20	6	6	6	6	2
88	21305-921	PANEL - REAR	1	1	1	1	1
90	51625-131	BASE	1	1	1	1	1
	51625-171	BASE	.	.	.	.	1
99	32001-151	CASTOR BRACKET CAP	4	4	4	4	4
100	51639-108	CASTOR BRACKET	2	2	2	2	2
101	51039-101	CASTOR BRACKET SUPPORT	2	2	2	2	2
102	10892-286	CASTOR	4	4	4	4	4
103	21039-301	TANK BRACKET	1	1	1	1	.
107	Y-12870	WASHER	8	8	8	8	8
113	10342-T14	SIDE BURNER ELECTRODE	1	1	1	1	1
114	53150-614	SHELF - RIGHT	1	1	1	1	1
115	53150-654	SHELF - SB - LEFT	1	1	1	1	1
123	Y-12117	BUSHING	2	2	2	2	2
124	23090-27	SIDE BURNER BODY	1	1	1	1	1
125	23000-253	SIDE BURNER COVER	1	1	1	1	1
126	20395-2A	SIDE BURNER	1	.	1	.	.
	20395-3A	SIDE BURNER	.	1	.	1	.
	20395-6A	SIDE BURNER	.	.	.	.	1
127	18670	BURNER SCREEN	1	1	1	1	1
128	23001-79	GRID	1	1	1	1	1

**PARTS LIST / LISTE DES PIÈCES**

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8759-62</u>	<u>8759-63</u>	<u>8759-82</u>	<u>8759-83</u>	<u>8759-86</u>
129	Y-11990	HEX NUT	.	.	1	1	1
130	27905-354	BURNER ROTISSERIE	.	.	1	1	1
131	10693-099	REAR BURNER-ORIFICE	.	.	1	.	.
	10693-104	REAR BURNER-ORIFICE	.	.	.	1	.
	10693-161	REAR BURNER-ORIFICE	.	.	.	.	1
133	S15271	HANDLE	.	.	1	1	1
134	S15270	BALANCER	.	.	1	1	1
135	S15299	WASHER	.	.	1	1	1
136	S15263	BUSHING	.	.	1	1	1
137	S15256	SPIT ROD	.	.	1	1	1
138	S15287	4 PRONG FORKS	.	.	2	2	2
139	57039-901	ROTISSERIE BRACKET	.	.	1	1	1
140	S21125S	SCREW #8 X 1/2	8	8	8	8	8
141	Y-11559	BOLT 1/4-20 X 1	2	2	2	2	2
144	Y-12220	BUSHING	.	.	.	.	1
145	S21235	HINGE PIN	2	2	2	2	2
146	S21233	HITCH PIN CLIP	2	2	2	2	2
147	Y-11231	LID BUMPER	4	4	4	4	4
148	10240-20	DOOR PIN	2	2	2	2	2
149	Y-11551	SHOULDER SCREW 1/4-20 X 1	2	2	2	2	2
150	Y-12124	DOOR PIN CAP	2	2	2	2	2
151	Y-12857	WASHER	4	4	4	4	4
152	Y-12229	MAGNET	1	1	1	1	1
153	Y-12223	MAGNET - PUSH IN	2	2	2	2	2
154	Y-12129	WIRE CLIP	2	2	2	2	2
155	S21124	SCREW #8 X 1/2	8	8	8	8	8
157	Y-12835	SCREW #6-32 X 1/4	.	.	2	2	2
158	Y-12646	SCREW SHOULDER #8 X 1/2	2	2	2	2	2
159	S21127S	SCREW #8-32 X 7/16	17	17	19	19	19
160	Y-29304	SCREW #10-24 X 3/8	6	6	6	6	6
161	Y-12310	SCREW 1/4-20 X 3/4	8	8	8	8	8
163	S35094	SCREW #10-24 X 5/8	4	4	4	4	4
169	S21061	WING NUT	.	.	2	2	2
170	S15517-011	ELECTRODE ASSEMBLY	1	1	1	1	.
	S15517-018	ELECTRODE ASSEMBLY	.	.	.	.	1
171	S15246	MOTOR	.	.	1	1	1
172	S15524	ELECTRODE	.	.	1	1	1
173	S21362	SPRING	.	.	1	1	1
180	S35095	SCREW #10-24 X 5/8	.	.	2	2	2
181	25030-73	WIRE - BATTERY PACK	1	1	1	1	1
181A	25070-95	LIGHT SWITCH	1	1	1	1	1
184	25080-80	BATTERY PACK	1	1	1	1	1
186	Y-12865	SCREW 1/4-20 X 3/4	52	52	52	52	48
190	25020-83	WIRE - LED LIGHT	1	1	.	.	.
	25020-84	WIRE - LED LIGHT	.	.	1	1	1
191	25020-82	WIRE - LED LIGHT	1	1	1	1	1

