



MOUNTING GUIDELINES

1. The preparation of the area. The construction of the floor and walls must be finished prior to the installation of the bathtub. The relevant pipes and fittings should be mounted not to interfere the set-up of the bathtub.

Structural measurements should be verified against the actual bath received to ensure proper fit.

If water mixers are mounted in the bathtub, hot and cold water outputs with 1/2" thread must be placed beneath the bathtub.

If you plan to place the bathtub in a niche, the length of the niche must be at least 5mm longer than the length of the bathtub, in case the bathtub shell thermally expand when filled with hot water.

2. Place the bathtub in the desired position and lift it to a side.

3. Adjust the level and the height of the bathtub by a level measurer and adjustable struts beneath the bathtub.

4. Install the waste and overflow system.

5. Connect the siphon to the drainage. The drainage inlet \varnothing 50 mm has to be at the floor level or 5 cm max above the floor and in at least 20cm radius from the bath's outlet. Please, make an opening in the lower part of the bathtub and use additional fittings and extensions if necessary.

6. Fill the gap between the bathtub and the wall with a waterproof sealant, if necessary. It is advised to fill the bathtub with water before the sealant has dried and leave the water in the tub for 24 h.

Please note that every bathtub installation case is individual and unique, therefore it is recommended to use the services of a certified plumber!