



DC305(A/G) DC306(A/G/E) DC307(A/G) DC313(A/G/E) Function Description


Transmitter: You can choose single channel (DC305(A/G)), five channels (DC306(A/G/E)), Each indicator light means one control channel. Press "channel choose" button P1-(indicator move left side) or P1+(indicator move right side) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. All indicator lights flash that means all channels is effective(group control state).

Transmitter: You can choose nine channels (DC307(A/G)) fifteen channels (DC313(A/G/E)). One number of LCD screen means one control channel. Press "channel choose" button P1-(number descending) or P1+(number increasing) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. If LCD screen number show 0 that means all channels is effective(group control state).


- **Notice:** transmitter Do not exposed to moisture and strike, so as not to affect life.
- When you use transmitter, if found emission distance obviously short or less sensitive, please change another same new battery. Please have batteries for recycling.




Matchable R Tubular Motor Set up



Matchable DC227/DC228 Tubular Motor Set up



Matchable DC136 Tubular Motor Set up



DC305(A/G) DC306(A/G/E) DC307(A/G) DC313(A/G/E)

Emitter Specification

Version No.: A/05



Type Specification

<p>UP Stop Down</p> <p>DC305(A) DC305G</p>	<p>UP Stop Down</p> <p>DC306(A) DC306E</p>	<p>Setting button</p> <p>DC305(A/G) DC306(A/G/E) Back</p>
<p>UP Stop Down</p> <p>DC307(A) DC307G</p>	<p>UP Stop Down</p> <p>DC313(A) DC313E</p>	<p>Setting button</p> <p>DC307(A/G) DC313(A/G/E) Back</p>

DC305G DC306G DC307G DC313G DC313E and DC305(A) DC306(A) DC307(A) DC313(A) have different button mark, but the function is the same.